





Read this before
turning ON
instrument!

Release lever **MUST** be moved
to the UNLOCK position
before turning ON instrument!
Failure to do so can
result in instrument damage.




*Shipping Brace Transport
Handle location*

Step 1:




Remove

Step 2:



Push

Step 3:



Turn & Lock